





**i**


 x1


 1 min




 [www.my-unilux.com](http://www.my-unilux.com)

**+**

**(A)** x1 

**(B)** x1 




100 cm



60 cm

30 cm


**1**



**2**


**(A)**



**(A)**

**+**

**(B)**



### HOW TO WASH IT ?

Use water and soap with a delicate textile to clean the surface of the roller feet.

