











<p>i</p> <p>x1  5 min  </p> <p> www.my-unilux.com</p>	<p>+</p> <p> (A) x1</p> <p> (B) x1</p> <p> (C) x1</p> <p> (D) x1</p>
--	--


1 Put the PVC balloon inside the felt cover




2 Put the valve right next to the closing zip and begin to pump around 4 mins



3 When the balloon is almost inflated, fold down, close the felt cover and finish inflating




4 When the balloon is fully inflated as desired, remove the pump and push in the cap




5

Close fully the zip of the felt cover



Max.
150 kg



The benefits of ERGO SPHERE

