





i

 **x1**

 **1 min**




 www.my-unilux.com


+

A

x1





+



1AA1,5V(supplied)
Average consumption: 0,20mA


1





37,5
cm


2



1- Remove the battery


2- Remove the plastic around the battery

3



Put back in the battery

4



Turn the wheel to set the time