





i

 x1


 1 min



 www.my-unilux.com


+

A x1




B x1

AA1,5 V




1



57,5 cm


2



1- Remove the battery


2- Remove the plastic around the battery

3



Put back in the battery

4



Turn the wheel to set the time