









i   
x1 1 min

 www.my-unilux.com


+   **B** x1
x1 AA1,5 V

1 




30 cm

2




1- Remove the battery
2- Remove the plastic around the battery

3



Put back in the battery

4



Turn the wheel to set the time